



# Which RepairKit do i need

## M6

### Repair-Kit




Screw Diameter 6mm (M6)



The screws for the brushes are always the same

## M8

### Repair-Kit



Screw Diameter 8mm (M8)

